


# PARTS BREAKDOWN FOR CONTROL BOXES AND WIRING HARNESES



| <u>Ref</u> | <u>Description</u>              | <u>Part#</u>  | <u>Qty</u> |
|------------|---------------------------------|---------------|------------|
| 1          | Power lead tractor              | 006-5650A     | 1          |
| 2          | Power lead baler                | 006-5650B     | 1          |
| 3          | Communication harness (baler)   | 006-5650D     | 1          |
| 4          | Communication harness (tractor) | 006-5650C     | 1          |
| 5          | Ram mount                       | 001-2012H     | 1          |
| 6          | Terminating resistor            | 006-5650Z     | 2          |
| 7          | Precision information processor | 006-5671LS    | 1          |
| 8          | End of bale sensor              | 006-7400      | 1          |
| 9          | End of bale sensor bracket      | 001-4648      | 1          |
| 10         | Display                         | 006-5670      | 1          |
| NP         | Dust cap                        | 006-5650PLUGS | 1          |