


# PARTS BREAKDOWN FOR CONTROL BOX AND WIRING HARNESS



<u>Ref.</u>	<u>Description</u>	<u>Part#</u>
1	Power Lead Tractor	006-4640A
2	Power Lead Baler	006-4660R
3	Baler Mounted Processor	006-4671RB
4	Communication Harness (baler)	006-4660S
5	Communication Harness (tractor)	006-4660N
6	Ram Mount	001-2012H
7	463 Terminal	006-4670
NP	Dust Plugs	006-4660PLUGS